

Can-Am Spyder RT

Trunk Mounted Flag Holders

#FH400

1. The FH400 flag holder is designed to be mounted under the trunk lid using the screws located there at the outer corners of the trunk under the lid attaching to the trunks main compartment or lower half.
2. Open the trunk lid - then remove the 4 Torx screws located at the rear corners of the trunk. Place 2 of the supplied plastic washers into the recesses where the four screws were removed. Place the 4 remaining steel washers onto the 6 x 25 mm Button head screws supplied.
3. Place the flag pole and bracket assemblies on the lid of the trunk, aligning the holes in the brackets with those in the trunk, and then install the screws with washers finger tight. While holding the bracket in against the trunk (so the bends are flush up to the vertical side or lip of the trunk) - tighten the screws securely.
4. Close the lid and check that the bracket is not putting pressure on the lid or preventing the lid from closing properly. If it is - loosen the screws and realign the bracket to gain the desired clearance and then retighten the screws.
5. Check the poles base nut and locking nut for tightness. Remove the top finial nut and two plastic clips from the poles. Slide your flags over the poles, and then, after adding a drop of blue Loc-Tite Medium Strength thread locker to the finial nut, re-attach and tighten the finial nut. Press the plastic clips over the material of the flag and pole using one at the bottom and top of the flag.



**440 South Pine Street
Burlington, WI 53105
888-801-8222
rivcoproducts.com**

*To complete your warranty and see hundreds of bagger
and cruiser products, please visit our website.*