

## QUICK DETACH RACK for HARLEY-DAVIDSON FLH & FLT Part # QD1000

**NOTE:** The use of the following items GL18010, GL18008, QD1000 and PF1000 on any un-sprung trailer hitch (examples: Voyager Trike Conversion Hitches, any hitch on a Can-Am Spyder, or any other un-sprung hitch) will void the warranty. These items were not designed to handle the excessive vibration and impacts from un-sprung trailer hitches, and the items may be damaged when used on these applications.

**Note:** To mount this to the motorcycle you will need to purchase a model specific mounting kit.

HWK015 – for 2008 and Older Harley-Davidson FLH and FLT models

HWK020 – for 2009-2013 Harley-Davidson FLH and FLT models

1. Assemble the rods onto the rack as shown below and as follows. Place one of the ¼" washers supplied onto each of the four ¼" button head screws supplied. Place the longer bolts thru the rear holes in the rack and then thru the holes in the rods and install the thinner lock nuts finger tight. Place the shorter bolts thru the front holes on the rack, bend the "P" clamps open and slide over the rods as shown. Close the "P" clamps with pliers, place the bolt thru the clamps, and install the remaining supplied lock nuts finger tight.

Proceed with the instruction enclosed with one of the mounting kits listed above

